

The Danphone Audio Hub expands the PCs audio signals and adds a push-to-talk feature. It lets the operator select loudspeaker, wired and wireless headsets, headphones with external microphones, microphones with push-to-talk (PTT) buttons and foot-switches.

The Danphone Audio Hub is controlled via USB.

## **KEY FEATURES**

- Audio Connections: Stereo loudspeaker for separate work (right) and monitor (left) channels.
  - Table microphone (gooseneck) with PTT button.
  - Wired and Wireless Headset with Microphone and PTT button. Handset with built-in speaker, microphone and PTT button.
  - Footswitch for handsfree PTT.
- **PC Connections:** Line out, Line in, USB 1.0 or newer.
- Microphone inputs: 10-100 mV<sub>RMS</sub> in, with phantom supply.
- Speaker Out: 245 mV<sub>RMS</sub>. 650 mV<sub>P. MAX</sub>.
- **PC Line In:** Stereo line level (245 mV<sub>RMS</sub>).
- **PC Line out:** Stereo line level (245 mV<sub>RMS</sub>).
- **Indicators:** Green indicator lights for Power, Red light for PTT button pressed.
- **Dimensions:** 12 x 8 x 2.5 cm (4.7" x 3.2" x 1.0").
- **Environment:** 0 to +40°C, Humidity up to 95% non-condensing.
- **Power:** Via USB, <0.5 A.

